Tips and Tricks


Extending the reach of your Plamp II _

If you need more reach one option is to attach the Plamp II to an object other than your own tripod. Another option is to extend the length of your Plamp by adding extra links to its arm. We sell a 12" long extension (part # PP-222). The trade-off to adding extra length to your Plamp is that it becomes less rigid.



Reconnecting the ball-and-socket joints of your Plamp

If the articulating arm is bent forcefully beyond its normal range of motion, it is possible for the segments to pop out of joint. Fixing this is simply a matter of popping the segments back together. If you have a hard time reconnecting the joints (we realize it takes quite a bit of force), you can warm the socket (female) end in hot water (boiling or near-boiling). This will cause the socket to expand and make it easier to pop the ball portion into place.



Fine control using the Plamp Rod Extension

For extra dexterity try using the Plamp Rod Extension in conjunction with the Ground Plamp or a Plamp II connected to a tripod leg or Plamp Stake.

